Move the remote close to the USB dongle. Check that a solid or flashing blue LED can be seen on the dongle. If not, plug the dongle into a different USB port. If the dongle light remains flashing blue when the remote's logo is flashing red, try recharging your remote. If the problem persists, check out the PAIRING section of the User Guide.