

## AMULET VOICE REMOTE - QUICK REFERENCE GUIDE

What Time Is It?

### MUSIC

#### Go To Music

Show ...

ARTISTS

ARTIST {*artist name*}

ALBUM {*album name*}

SONG {*song name*}

Play ...

ARTIST {*artist name*}

ALBUM {*album name*}

SONG {*song name*}

PLAY SOMEONE ELSE

PLAY ANOTHER ALBUM

PLAY SOMETHING ELSE

#### PLAYLISTS

WHAT PLAYLISTS DO I HAVE

SHOW PLAYLISTS

SHOW CURRENT PLAYLIST

#### GENRES

SHOW GENRES

PLAY SOME {*genre name*}

PLAY ANOTHER GENRE

#### FAVOURITES

SHOW FAVOURITES

RATE THIS SONG AS [1-5] Stars

PLAY FAVOURITES

#### CONTROL

STOP SONG

PAUSE SONG

CONTINUE

NEXT / PREVIOUS SONG

FAST FORWARD SONG

SHUFFLE ON / OFF

REPEAT ON / OFF

SHOW / HIDE SONGS

#### INFO

NAME THAT SONG

WHO SINGS THAT

WHAT SONG IS THIS?

SHOW WHAT'S PLAYING

SHOW NOW PLAYING

### Go To COMMANDS

#### AMULET

Go To Music

Go To SLIDESHOW

Go To RECORDED TV

Go To VIDEOS

Go To TV GUIDE

Go To MOVIES

#### MEDIA CENTER

Go To START

Go To My Music

Go To My Music ARTISTS

Go To My Music ALBUMS / SONGS

Go To My PICTURES

Go To My VIDEOS

Go To MORE PROGRAMS

Go To VISUALIZATION

Go To MOVIE LIBRARY

Go To SCHEDULED TV RECORDINGS

Go To SLIDESHOW SETTINGS

### COMMON COMMANDS

#### NAVIGATION

GO LEFT [1 TO 9]

GO RIGHT [1 TO 9]

PAGE UP / DOWN

NEXT PAGE

PREVIOUS PAGE

GO UP [1 TO 9]

GO DOWN [1 TO 9]

SELECT

OKAY

#### VOLUME

SOUND ON / OFF

VOLUME UP / DOWN

SOFT VOLUME

MEDIUM VOLUME

NORMAL VOLUME

LOUD VOLUME

FULL VOLUME

QUIET

### PHOTOS

Go To PHOTOS

PLAY SLIDESHOW {*name*}



amulet devices

**MOVIES / FILMS**    WHAT MOVIE IS THIS?

PLAY / WATCH / SHOW MOVIE **{name}**

Show ...    Go To MOVIES

ALL  
RECENT  
**{genre}**  
... Movies

PLAY / WATCH / SHOW **{name}**  
NEXT CHAPTER  
PREVIOUS CHAPTER

SHOW NOW PLAYING

**VIDEOS**

PLAY / WATCH / SHOW VIDEO **{name}**

Show ...    PLAY / WATCH **{name}**  
HOME MOVIES    NEXT CHAPTER  
VIDEOS    PREVIOUS CHAPTER  
HELP VIDEOS

SHOW NOW PLAYING

PAUSE VIDEO    STOP VIDEO  
PLAY VIDEO    CONTINUE

**NAVIGATION**

FAST FORWARD  
FAST REVERSE  
REWIND  
FAST REWIND  
SLOW MOTION

**SKIP**    SKIP OVER ADS    SKIP TO START

SKIP TO **{position}**

SKIP FORWARD **{timespan}** / SKIP BACK **{timespan}**

**{position}** and **{timespan}** are times in seconds, minutes and seconds, or hours, minutes and seconds. For example, "100 seconds", "2 minutes and 50 seconds", and "one hour and 25 minutes" are all valid.

**TV PROGRAMS**

PLAY / SHOW / DELETE ...

PROGRAM  
TV SHOW  
TV SERIES  
SERIES  
... **{name}**

SHOW TV PROGRAMS  
SHOW RECORDED TV

SHOW **{name}**  
PLAY / WATCH **{name}**  
DELETE **{name}**

PAUSE PROGRAM  
PLAY PROGRAM  
STOP PROGRAM  
CONTINUE

WHAT PROGRAM IS THIS?

**LIVE TV**

WATCH CHANNEL **{name}**    WHAT PROGRAM IS THIS?

RECORD THAT    PAUSE PROGRAM / PLAY PROGRAM

**TV GUIDE**

SHOW GUIDE AT **{time}** ON **{date}**

SHOW CHANNEL **{channel}** AT **{time}** ON **{date}**

SHOW DATE **{date}**

SHOW TIME **{time}**

**{channel}** is a channel name or NUMBER and a number.  
**{time}** is a time such as 22:00, 12 pm, 8:30 pm, etc.  
**{date}** is any date or day within the next three weeks, such as 17 March, Tomorrow, Friday, Next Tuesday.

NEXT DAY / PREVIOUS DAY  
NEXT WEEK / PREVIOUS WEEK

**UPDATE MEDIA**

UPDATE MOVIES    UPDATE VIDEOS  
UPDATE MUSIC    UPDATE TV  
UPDATE PHOTOS    UPDATE CHANNEL NAMES

## SELECTING MEDIA BY NAME

PLAY SHOW

SLIDESHOW ARTIST

VIDEOS PROGRAM

MOVIE TV SERIES

*{Item Name}*

## BROWSING YOUR MEDIA

Go To

MUSIC RECORDED TV

MOVIES TV SERIES

PHOTOS TV GUIDE

HOME MOVIES VIDEOS

