

Check the battery installation and place the remote on charge. See the installation section and the Amulet Remote Hardware video for guidance.