

Your Amulet Voice Remote includes these additional buttons and capabilities. See the next chapter for more information about how to program them.

### **Profile button**

Press to identify the current speech profile. Pressing it again will switch to a new profile.

### **Music button**

This goes to the Media Center Music Library. You can reprogram it to send a TV device code such as select source video input.

### **Device selection buttons**

These colored buttons are also used to select one of four button keymaps for controlling other equipment.