

Your Amulet Voice Remote includes these additional buttons and capabilities. See the next chapter for more information about how to program them.

Profile button

Press to identify the current speech profile. Pressing it again will switch to a new profile.

Music button

This goes to the Media Center Music Library. You can reprogram it to send a TV device code such as select source video input.

Device selection buttons

These colored buttons are also used to select one of four button keymaps for controlling other equipment.